

Concrete Finishing & Resinous Floor Coating Shoes

It's never been easier to install epoxy coatings or self-leveling and decorative overlays. With a patented design, Shoe-In® Pro shoes are a fantastically simple and affordable solution with multiple applications.

APPLICATIONS INCLUDE:

Installing Epoxy Coatings | Installing Concrete & Screed Floors Including Decorative Overlays
Industrial Environments | Renovations or Removals | Any Area Where Flooring Needs Protecting



SLIPS ON IN SECONDS

HANDS FREE! PUT AN END TO FRUSTRATIONS WITH STRAPS, BUCKLES AND ADJUSTMENTS ON TRADITIONAL FLOOR FINISHING SHOES.

COMFORTABLE

GOES OVER YOUR EXISTING SHOES OR BOOTS. STAYS SNUG WHETHER YOU'RE STANDING OR KNEELING. WIDE BASE FOR STABILITY.

TIME SAVING

ALLOWS YOU TO TAKE PROTECTIVE SHOES ON AND OFF AS NEEDED TO GET THE JOB DONE.



FLAT STYLE

FOR CONCRETE INSTALLATION. NO TREAD MARKS OR HEEL MARKS. IDEAL FOR DECORATIVE CONCRETE STAMPING AND GENERAL SURFACE TROWELING.



SHARP SPIKED STYLE

3/4" - FOR RESINOUS / EPOXY FLOOR COATING INSTALLATION. MARK-FREE INSTALLATIONS. SHARP OR ROUNDED REPLACEMENT SPIKES ARE AVAILABLE.

Item No.	Description
46161	Concrete Finishing Shoe - Medium
46162	Concrete Finishing Shoe - Large
46163	Concrete Finishing Shoe - Extra- Large

Item No.	Description
46171	Spiked Shoes - 3/4" Sharp - for Resinous Coatings - Medium
46172	Spiked Shoes - 3/4" Sharp - for Resinous Coatings - Large
46173	Spiked Shoes - 3/4" Sharp - for Resinous Coatings - Extra-Large
46131	Replacement Spikes - 3/4" Sharp (Set of 32 - 16 Per Shoe)
46132	Replacement Spikes - 1" Rounded (Set of 32 - 16 Per Shoe)

SIZING - SELECT YOUR SIZE TO FIT OVER EITHER BOOTS OR SNEAKERS

MEDIUM

FITS BOOT SIZE 9 AND UNDER
FITS SNEAKER SIZE 9 AND UNDER

LARGE

FITS BOOT SIZES 10 TO 11
FITS SNEAKER SIZE 10 TO 12

EXTRA-LARGE

FITS BOOT SIZES 12 TO 16
FITS SNEAKER SIZE 13 TO 16